

## SECC Manhole set up process

### Summary of work procedure:

1. Set up work area protection
  - A. To protect employee/s
  - B. To protect the public
  - C. To protect the work area
2. Test the manhole
  - A. Test manhole for gasses
  - B. Record the readings on SECC log
  - C. Purge manhole for the required time.
  - D. Continue monitoring manhole for gasses
3. During the work day
  - A. If leaving manhole release blower house for removal
  - B. If the blower is turned off and manhole is going to be vacated for a short time
  - C. Remove blower from manhole
  - D. Retest manhole prior to reentering verify readings with initial test
  - E. Turn blower on and purge blower before re lowering blower into manhole

### Important information:

1. For ventilation use Nomograph sheet
2. Qrae Gas Meter readings information sheet

**\*Note:** SECC does not do work in ***“Permit Required Confined Spaces”***.